

GOXTREME[®]

ACTION CAMS

RIDE THE ELEMENTS



FULL HD
1080
60fps



170°
VIEW



45m
WATERPROOF



2.0" 5cm
DISPLAY



ACCESSORIES
INCLUDED



GOXTREME[®] WiFi SPEED

HIGH SPEED FULL HD ACTION CAM

1080p (1920x1080) 60fps VIDEO | WIFI FUNCTION

2.0"/5cm DISPLAY | 170° WIDE ANGLE

WATERPROOF CASE UP TO 45m | WRIST REMOTE CONTROL





GoXtreme® WiFi SPEED

| | |
|---------------------------|--|
| Display | 2.0"/5cm |
| Waterproof case | Up to 45m waterproof |
| Image sensor | 8M CMOS Sensor |
| Still imageresolution | 16M (4640x3480) by interpolation, 8M (3264x2448), 5M (2592x1944), 4M (2304x1728) |
| Image file format | JPG |
| Video resolution | 1440p (1920x1440) 30fps (4:3) 1080p (1920x1080) 60fps / 30fps (16:9) 720p (1280x720) 120fps / 60fps (16:9) |
| Video file format | MOV, H.264 compression |
| Video with sound | Yes |
| WiFi function | Yes |
| Wrist remote control | To make movies/pictures and to power off the camera (no power on function!) |
| Memory | Micro SD card support up to 32GB minimum Class 6 (not included) |
| Microphone | Build-in |
| Speaker | Yes |
| Aperture | F3.1 f=2.9mm |
| Shutter control | Electronic |
| Focus | Fixed Wide angle 170° |
| EV compensation | Auto |
| Sensitivity | Auto |
| White balance | Auto |
| Slow motion video | 720p (120fps) / 1080p (60fps) for slow motion video playing on a PC |
| OSD language | EN, FR, NL, ES, IT, PT, DE, CZ, PL |
| Playback | YES (Connect the USB/HDMI) |
| PC interface | USB 2.0 |
| HDMI port | YES |
| Power source | 1200mAh lithium battery (exchangable) |
| Dimensions | 59 x 44 x 25.5mm, 70g |
| Working temperature | -5 °C to +40 °C |
| System requirements | Microsoft® Windows® 2000, XP, Vista, |
| for mass storage function | Win7, Win 8, Mac OS X 10.0.0 or above |



ACCESSORIES INCLUDED

| | |
|------------------------|----------------------|
| Waterproof case | Wrist remote control |
| Protection shield | Car charger |
| Surfboard mount | Battery |
| Bike mount | USB cable |
| Helmet mount with band | Manual CD |
| Sticker | |

Download the „SYMAGIX2“ app from App Store or Google Play and connect the action cam to your iOS or Android device via WiFi. You can control your action cam by your phone or tablet or you can transfer images or videos to your device and share them with your friends.



SYMAGIX2



easypix®
LIFESTYLE ELECTRONICS

